




# User manual

Dual view air fryer

---




## Description of parts



1. Air fryer main unit
2. Cooking compartment
3. Cooking compartment handle
4. Power button
5. Temperature control buttons
6. Match cook button
7. Non-stick coated cooking tray
8. LED display

9. Function buttons
10. Compartment divider
11. Sync cook button
12. Time control buttons
13. Start/pause button
14. Viewing window
15. Digital control panel

Please retain instructions for future reference.



**WARNING:** If the power supply cord, plug or any part of the appliance is malfunctioning or if it has been dropped or damaged, cease using the product immediately to avoid potential injury.

## SAFETY INSTRUCTIONS

- When using electrical appliances, basic safety precautions should always be followed.
- Check that the voltage indicated on the rating plate corresponds with that of the local network before connecting the appliance to the mains power supply.
- Children aged from 8 years and people with reduced physical, sensory or mental capabilities or lack of experience and knowledge can use this appliance, only if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children should be supervised to ensure that they do not play with the appliance.
- Unless they are older than 8 and supervised, children should not perform cleaning or user maintenance.
- This appliance is not a toy.
- This appliance contains no user serviceable parts; only a qualified electrician should carry out repairs.
- Improper repairs may place the user at risk of harm.
- Keep the appliance and its power supply cord out of the reach of children.
- Keep the appliance out of the reach of children when it is switched on or cooling down.
- Keep the appliance and its power supply cord away from heat or sharp edges that could cause damage.

- Keep the power supply cord away from any parts of the appliance that may become hot during use.
- Keep the appliance away from other heat emitting appliances.
- Do not immerse the appliance in water or any other liquid.
- Do not operate the appliance with wet hands.
- Do not leave the appliance unattended whilst connected to the mains power supply.
- Do not remove the appliance from the mains power supply by pulling the cord; switch it off and remove the plug by hand.
- Do not use any accessories other than those supplied.
- Do not use the appliance for anything other than its intended use.
- Do not use this appliance outdoors.
- Do not store the appliance in direct sunlight or in high humidity conditions.
- Do not move the appliance whilst it is in use.
- Do not touch any sections of the appliance that may become hot or the heating components of the appliance, as this could cause injury.
- Do not use sharp or abrasive items with this appliance; use only plastic or wooden spatulas to avoid damaging the non-stick surface.
- Always unplug the appliance after use and before any cleaning or user maintenance.
- Always ensure that the appliance has cooled fully after use before performing any cleaning or maintenance or storing away.
- Always use the appliance on a stable, heat-resistant surface at a height that is comfortable for the user.
- Use of an extension cord with the appliance is not recommended.
- This appliance should not be operated by means of an external timer or separate remote control system, other than that supplied with this appliance.
- This appliance is intended for domestic use only. It should not be used for commercial purposes.
- The outer surface or door may get hot during operation.



**CAUTION:** Hot surface – do not touch any sections or surfaces of the appliance that may become hot or the heating components of the appliance.



**WARNING:** Keep the appliance away from flammable materials.

## Automatic switch-off

The air fryer is fitted with an automatic switch-off. This may activate if the set cooking time has elapsed, causing the timer to sound and the automatic switch-off to activate, turning off the air fryer.



**NOTE:** If the air fryer needs to be turned off before the set cooking time has elapsed, switch off and unplug it from the mains power supply.

## Dos and don'ts

### DO:

Check that the cooking compartment is securely fitted before use. Not doing so will prevent the air fryer from operating.

Only hold the cooking compartment by the cooking compartment handle. Take care when removing the cooking compartment, as steam may be emitted.

Make sure divider is fully inserted if using.

### DON'T:

Invert the non-stick coated cooking tray with the cooking compartment still attached, as excess oil may collect at the bottom of the cooking compartment, and could leak into the ingredients.

Cover the air fryer or its air inlets, as this will disrupt the airflow and could affect the cooking results.

Fill the cooking compartment with oil or any other liquid.

Touch the cooking compartment during or straight after use, as it gets very hot; only hold the cooking compartment by the handle.

Use air fryer liners or similar products.

## Care and maintenance

Before attempting any cleaning or maintenance, switch off and unplug the air fryer from the mains power supply and allow it to fully cool.

**STEP 1:** Wipe the air fryer main unit with a soft, damp cloth and dry thoroughly.

**STEP 2:** Clean the non-stick coated cooking tray and the cooking compartment in warm, soapy water, then rinse and dry thoroughly.

Do not immerse the air fryer main unit in water or any other liquid.

Never use harsh or abrasive cleaning detergents or scourers to clean the air fryer or its accessories, as this could cause damage.



**NOTE:** The air fryer should be cleaned after each use.

## Instructions for use

### Before first use

**STEP 1:** Before connecting the air fryer to the mains power supply, wipe the air fryer main unit with a soft, damp cloth and dry thoroughly.

**STEP 2:** Clean the non-stick coated cooking tray, compartment divider and the cooking compartment in warm, soapy water, then rinse and dry thoroughly.

**STEP 3:** Place the air fryer main unit onto a stable, heat-resistant surface, at a height that is comfortable for the user.



**NOTE:** When using the air fryer for the first time, a slight smoke or odour may be emitted. This is normal and will soon subside. Allow for sufficient ventilation around the air fryer during use. It is advised to run the air fryer without food for approx. 10 minutes before first use; this will prevent the initial smoke or odour from affecting the taste of the food.

### Assembling the air fryer

**STEP 1:** Fit the non-stick coated cooking tray into the cooking compartment, checking that they are seated securely.

**STEP 2:** Slide the cooking compartment into the air fryer main unit.



**NOTE:** The air fryer comes preassembled. The cooking compartment should be closed securely before use, as not doing so will prevent the air fryer from working.


### Using the divider

**STEP 1:** To use the large compartment, ensure that the divider is removed from the cooking compartment. To separate the compartment into two individual sections, ensure that the divider is slotted in place.



**NOTE:** To make sure the divider is slotted in the correct way, ensure that the guide arrows on the divider is pointing up; it should slot in easily. Do not force the divider in as this may cause damage to the air fryer. The air fryer comes preassembled. The cooking compartment should be closed securely before use, as not doing so will prevent the air fryer from working.

## Using the control panel



When the air fryer is plugged in and switched on at the mains power supply, it will beep and the power button will illuminate to indicate that it is being powered.

Tap the power button to switch on the air fryer.

### Manual setting

The time and temperature can be set manually; time and temperature values are dependent on the food being cooked.

Lines will appear on the LED display, indicating the air fryer is ready to be programmed.

Select the relevant compartment by tapping '1' or '2'.

To adjust the setting manually, press the manual button, then the time control buttons to change the cooking time, up to a max. of 60 mins (or up to a max. of 12 hours for dehydration).

Tap the temperature control buttons to adjust the cooking temperature from 40 to 210 °C (or max. 90 °C for dehydration).

To use only one compartment, do not select any settings for the other.

Press the start/pause button to begin cooking.



**NOTE:** Refer to the recipe booklet for additional information and cooking guidelines.

### Preset functions

**STEP 1:** Press one of the function buttons to use a preset cooking function. The display will cycle automatically between the preset time and temperature. These presets can then be adjusted using the time and temperature control buttons as required.

The time and temperature control buttons may be held down in order to quickly adjust the time or temperature.

**STEP 2:** Press the start/pause button to begin heating when the time and temperature have been set. Time and temperature can be changed during use by tapping the drawer number and using the time and temperature control buttons.

**STEP 3:** Once cooking is complete and the preset time has elapsed, the timer will sound and the air fryer will switch off.

**STEP 4:** To switch off the air fryer, press and hold the power button.



**NOTE:** If the cooking compartment is removed during cooking, the air fryer will stop cooking; reinsert the cooking compartment to resume the cooking process.

## Cooking Functions

Function	Pre-set temperature	Temperature range	Time
Air fry	210 °C	80–210 °C	Max. 1 hour
Roast	190 °C	120–210 °C	Max. 4 hours
Bake	160 °C	120–210 °C	Max. 4 hours
Dehydrate	60 °C	40–90 °C	Max. 12 hours
Manual	180 °C	40–210 °C	Max. 1 hour
Reheat	170 °C	130–210 °C	Max. 1 hour

## Using the sync cook setting

When cooking different foods in the divided compartments with different times and temperatures, use the sync setting so that both sections finish cooking at the same time.

**STEP 1:** Tap ‘1’ and set the required settings for the first cooking compartment, following the instructions in the section entitled ‘**Using the control panel**’.

**STEP 2:** Repeat for the second cooking compartment by tapping ‘2’.

**STEP 3:** Press the sync cook button; the button will illuminate to signal that the setting has been selected.

**STEP 4:** Press the start/pause button to begin cooking.

## Using the match cook setting

Use the match setting when using the divided compartments to cook the same foods; cooking will finish at the same time for both compartments.



**STEP 1:** Tap '1' and set the required settings for the first divided cooking compartment, following the instructions in the section entitled '**Using the control panel**'.

**STEP 2:** Press the match cook button; the button will illuminate to signal that the setting has been selected.

**STEP 3:** Press the start/pause button to begin cooking.



**NOTE:** The power button will remain illuminated whilst the unit is plugged in.

## Using the air fryer

**STEP 1:** Plug in and switch on the air fryer at the mains power supply; the air fryer will beep, and the power button will illuminate to indicate that the unit is plugged in.

**STEP 2:** Tap the power button to switch on the air fryer; the display functions will show, indicating the air fryer is ready to be programmed.

**STEP 3:** Following the instructions in the section entitled '**Using the control panel**', use the time and temperature control buttons to increase or decrease the time or temperature as required.

**STEP 4:** Once preheated, remove the cooking compartment by pulling it out of the air fryer using the handle. Position the cooking compartment onto a flat, stable, heat-resistant surface.

**STEP 5:** Place the ingredients into the non-stick coated cooking tray and then slide the cooking compartment back into the air fryer main unit to close it.

**STEP 6:** Use the digital control panel to set the cooking time and temperature as required for the ingredients. Time and temperature settings can also be set using the function buttons, which automatically cycle between time and temperature presets for cooking various foods when pressed. These presets can then be adjusted using the time and temperature control buttons as required.

**STEP 7:** Some ingredients may require shaking halfway through the cooking time. Remove the cooking compartment from the air fryer main unit using the cooking compartment handle. Shake the cooking compartment gently and then slide back into the air fryer main unit to continue cooking.

**STEP 8:** Once cooking is complete and the preset time has elapsed, the air fryer will beep several times and show '**END**' on the display. The air fryer will then switch off. Check whether the ingredients are ready; if the ingredients are not cooked, close the cooking compartment and replace

back into the air fryer main unit. Use the digital control panel to adjust the cooking time accordingly. If the food is cooked, empty the contents into a bowl or onto a plate. Use a pair of heat-resistant tongs (not included) if the food is large or fragile.



**NOTE:** Always preheat the air fryer before starting to cook. If the cooking time or temperature setting needs to be changed during use, use the time and temperature control buttons, as required. For foods with a high-water content, condensation may appear on the viewing window. This is normal and should clear after the air fryer has cooled down.



**CAUTION:** Do not tip the food directly into a bowl or onto a plate, as excess oil may collect at the bottom of the cooking compartment and leak onto the ingredients or serving bowl. Exercise caution when opening and closing the cooking compartment during use, as it will become very hot.

**WARNING:** Nominal voltage is still present even when the air fryer is switched off. To permanently switch off the air fryer, switch off and unplug from the mains power supply.

## Storage

Check that the air fryer is cool, clean and dry before storing in a cool, dry place. Never wrap the cord tightly around the air fryer; wrap it loosely to avoid causing damage.

## Specifications

Product code: EK5872

Input: 220–240 V ~ 50–60 Hz

Output: 2300 W





#### Disposal of Waste Batteries and Electrical and Electronic Equipment



This symbol on the product, its batteries or its packaging means that this product and any batteries it contains must not be disposed of with household waste. Instead, it is the user's responsibility to hand this over to an applicable collection point for the recycling of batteries and electrical and electronic equipment. This separate collection and recycling will help to conserve natural resources and prevent potential negative consequences for human health and the environment due to the possible presence of hazardous substances in batteries and electrical and electronic equipment, which could be caused by inappropriate disposal. Some retailers provide take-back services which allow the user to return exhausted equipment for appropriate disposal. **It is the user's responsibility to delete any data on electrical and electronic equipment prior to disposal.** For more information about where to drop batteries, electrical and electronic waste off, please contact the local city/municipality office, household waste disposal service, or the retailer.

Manufactured by:  
Ultimate Products UK Ltd.,  
Victoria Street, Manchester OL9 0DD. **UK.**  
Ultimate Products Europe Ltd.,  
19 Baggot Street Lower, Dublin D02 X658. **ROI.**  
**MADE IN CHINA.**

CD131023/MD000000/V1