


# User manual

Sandwich toaster



# Important safety

Please read carefully

Please retain instructions for future reference.

## SAFETY INSTRUCTIONS

- When using electrical appliances, basic safety precautions should always be followed.
- Check that the voltage indicated on the rating plate corresponds with that of the local network before connecting the appliance to the mains power supply.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities and knowledge, if they have been supervised/instructed and understand the hazards involved.
- Children shall not play with the appliance.
- Children should not perform cleaning or user maintenance, unless they are older than 8 and supervised.
- This appliance is not a toy.
- If the power supply cord, plug or any part of the appliance is malfunctioning or if it has been dropped or damaged, cease using the product immediately to avoid potential injury.
- This appliance contains no user serviceable parts, only a qualified electrician should carry out repairs. Improper repairs may place the user at risk of harm.
- Keep the appliance and its power supply cord out of the reach of children.
- Keep the appliance out of the reach of children when it is switched on or cooling down.
- Keep the appliance and its power supply cord away from heat or sharp edges that could cause damage.
- Keep the power supply cord away from any parts of the appliance that may become hot during use.
- Keep the appliance away from other heat emitting appliances.
- Do not allow the power supply cord to hang over worktops, touch hot surfaces or become twisted.
- Do not immerse the electrical components of the appliance in water or any other liquid.
- Do not operate the appliance with wet hands or if any connections are wet.
- If this appliance falls or accidentally becomes immersed in water, unplug it from the wall outlet immediately. Do not reach into the water.
- Do not leave the appliance unattended whilst connected to the mains power supply.
- Do not remove the appliance from the mains power supply by pulling the cord; switch it off and remove the plug by hand.
- Do not pull or carry the appliance by its power supply cord.
- Do not use the appliance for anything other than its intended use.
- Do not use any accessories other than those supplied.
- Do not use this appliance outdoors.
- Do not store the appliance in direct sunlight or in high humidity conditions.
- Do not move the appliance whilst it is in use.
- Always unplug the appliance after use and allow it to cool fully before any cleaning, user maintenance or storing away.
- Always use the appliance on a stable, heat-resistant surface, at a height that is comfortable for the user.
- This appliance should not be operated by means of an external timer or separate remote control system.
- Use of an extension cord with the appliance is not recommended.
- This appliance is intended for domestic use only. It should not be used for commercial purposes.




**CAUTION:** Hot surface – do not touch hot sections or heating components of the appliance.



**WARNING:** Keep the appliance away from flammable materials.

## Description of parts



1. Sandwich toaster main unit
2. Upper housing
3. Lower housing
4. Cool-touch handle
5. Handle lock

6. Red power indicator light
7. Green ready indicator light
8. Non-stick coated cooking plates
9. Non-slip feet

Please retain instructions for future reference.

## Care and maintenance

**STEP 1:** Before attempting any cleaning or maintenance, unplug the sandwich toaster from the mains power supply and allow to fully cool.

**STEP 2:** Wipe the sandwich toaster housing with a soft, damp cloth and dry thoroughly.

**STEP 3:** Remove baked-on food by applying a small amount of warm water mixed with a mild detergent to the non-stick coated cooking plates, then wipe them clean with a paper towel or nonabrasive scourer.

Never use harsh or abrasive cleaning detergents or scourers to clean the sandwich toaster, as this could damage the surface.



**NOTE:** The sandwich toaster should be cleaned after each use.

## Instructions for use

### Before first use

Before connecting to the mains power supply, clean the sandwich toaster following the instructions in the section entitled '**Care and maintenance**'.



**NOTE:** When using the sandwich toaster for the first time, a slight smoke or odour may be emitted. This is normal and will soon subside. Allow for sufficient ventilation around the sandwich toaster.

## Using the sandwich toaster

**STEP 1:** Prepare the sandwich that is to be toasted, taking care not to overfill the bread, as this could cause the ingredients to overflow.

**STEP 2:** Plug in and switch on the sandwich toaster at the mains power supply. The red power indicator light will illuminate, signalling that the sandwich toaster has been switched on and is heating up.

**STEP 3:** Preheat the sandwich toaster for approx. 3 minutes. The green ready indicator light will illuminate once the required temperature has been reached.

**STEP 4:** Carefully apply a thin coat of cooking oil to the non-stick coated cooking plates, rubbing it in carefully with a paper towel. This will help to prolong the life of the non-stick coating and stop the sandwich from sticking.

**STEP 5:** Place the prepared sandwich onto the lower non-stick coated cooking plate and then close the lid.

**STEP 6:** Toast the sandwich for approx. 2–4 minutes; check periodically by carefully opening the lid. If needed, the sandwich can be cooked a little while longer, until it is browned to preference.

**STEP 7:** Once cooking is complete, carefully open the lid and remove the toasted sandwich with a heat-resistant plastic or wooden spatula.

**STEP 8:** Switch off and unplug the sandwich toaster from the mains power supply and allow it to cool by leaving the lid open.



**NOTE:** Always preheat the non-stick coated cooking plates before starting to cook. During use the green ready indicator will cycle on and off to signal that the sandwich toaster is maintaining the temperature.



**CAUTION:** The non-stick coated cooking plates get very hot during use; always use heat-resistant gloves to avoid injury.



**WARNING:** Exercise caution during cooking; the sandwich toaster will emit steam. Do not toast pastries with runny fillings or frosting. Do not toast torn slices of bread. Do not allow bread to burn.

## Storage

Before storing in a cool, dry place, make sure that the sandwich toaster is cool, clean and dry.

Never wrap the cord tightly around the sandwich toaster; wrap it loosely to avoid causing damage.

## Specifications

Product code: EK2017N

Input: 220–240 V ~ 50/60 Hz

Output: 900 W

# RECIPES



## Cheese and chorizo

### Ingredients

2 slices granary bread

50 g cheddar, sliced

50 g chorizo

### Method

Evenly spread the cheddar and chorizo onto one slice of the granary bread.

Add the second slice of granary bread on top, to complete the sandwich.

Place the sandwich onto the lower non-stick coated cooking plate.

Close the lid and then cook the sandwich for approx. 3–4 minutes, until crispy.

## Chicken and mustard mayonnaise

### Ingredients

2 slices granary bread

50 g cooked chicken breast, thinly sliced

1 tbsp mayonnaise

1 tbsp French mustard

Handful of rocket

### Method

Combine the mustard and mayonnaise in a bowl. Add the chicken and mix well. Evenly spread the mixture onto one slice of the granary bread and then sprinkle on the rocket.

Add the second slice of granary bread on top, to complete the sandwich.

Place the sandwich onto the lower non-stick coated cooking plate.

Close the lid and then cook the sandwich for approx. 3–4 minutes, until crispy.

## Camembert and cranberry

### Ingredients

2 slices wholemeal bread

50 g camembert, sliced

1 tbsp cranberry sauce

Small handful of rocket

### **Method**

Combine the camembert and cranberry sauce in a bowl. Mix well.

Evenly spread the mixture onto one slice of the wholemeal bread and then sprinkle on the rocket.

Add the second slice of wholemeal bread on top, to complete the sandwich.

Place the sandwich onto the lower non-stick coated cooking plate.

Close the lid and then cook the sandwich for approx. 3–4 minutes, until crispy.

## **Tuna and cheese melt**

### **Ingredients**

2 slices granary bread

50 g tinned tuna steak, drained

25 g mature cheddar, grated

½ red onion, finely diced

1 tbsp mayonnaise

### **Method**

Combine the tuna steak, cheddar, red onion and mayonnaise in a bowl. Mix well. Evenly spread the mixture onto one slice of the granary bread.

Add the second slice of granary bread on top, to complete the sandwich.

Place the sandwich onto the lower non-stick coated cooking plate.

Close the lid and then cook the sandwich for approx. 3–4 minutes, until crispy.

## **Pesto, mozzarella and sundried tomato**

### **Ingredients**

2 slices thickly sliced, white bread

4 sundried tomatoes, sliced

50 g mozzarella, sliced

1 tbsp green pesto

### **Method**

Evenly spread the green pesto onto one slice of the white bread and then arrange the sundried tomatoes and mozzarella on top.

Add the second slice of white bread on top, to complete the sandwich.

Place the sandwich onto the lower non-stick coated cooking plate.

Close the lid and then cook the sandwich for approx. 3–4 minutes, until crispy.

## **Avocado, tomato and feta**

### **Ingredients**

2 slices granary bread

30 g feta, crumbled

½ tomato, sliced

¼ ripe avocado

### **Method**

Evenly spread the avocado, tomato and feta onto one slice of the granary bread.

Add the second slice of granary bread on top, to complete the sandwich.

Place the sandwich onto the lower non-stick coated cooking plate.

Close the lid and then cook the sandwich for approx. 3–4 minutes, until crispy.

## **Strawberry, banana and hazelnut chocolate**

### **Ingredients**

2 slices wholemeal bread

4 strawberries, sliced

½ banana, sliced

1 tbsp hazelnut chocolate spread

### **Method**

Evenly spread the hazelnut chocolate spread onto one slice of the wholemeal bread and then arrange the strawberries and banana on top.

Add the second slice of wholemeal bread on top, to complete the sandwich.

Place the sandwich onto the lower non-stick coated cooking plate. Close the lid and then cook the sandwich for approx. 3–4 minutes, until crispy.

## **Caramelised banana**

### **Ingredients**

2 slices wholemeal bread  
1 banana, sliced  
1 tbsp brown sugar  
1 tbsp butter  
Pinch of ground cinnamon

### **Method**

Using a frying pan, cook the banana in the butter for approx. 30 seconds.

Add the sugar and cinnamon to the frying pan and cook until the sugar has dissolved.

Evenly spread the mixture onto one slice of the wholemeal bread.

Add the second slice of wholemeal bread on top, to complete the sandwich.

Place the sandwich onto the lower non-stick coated cooking plate.

Close the lid and then cook the sandwich for approx. 3–4 minutes, until crispy.



Manufactured by:  
Ultimate Products UK Ltd.,  
Victoria Street, Manchester OL9 0DD. **UK.**  
Ultimate Products Europe Ltd.,  
19 Baggot Street Lower, Dublin D02 X658. **ROI.**  
**MADE IN CHINA.**

CD310325/MD000000/V1