

PROGRESS®

Est. 1931

VACUUM STORAGE CONTAINER

Instruction Manual

SAFETY INSTRUCTIONS

The vacuum storage container is not a toy. Keep out of the reach of children.

Do not place anything other than food into the storage pot.

Note: The vacuum storage container only helps to prolong freshness of food; it cannot indefinitely preserve the food nor can it create a sterile environment.

BEFORE FIRST USE

Hand-wash the storage pot in warm, soapy water. Rinse and dry thoroughly.

Do not submerge the lid in water; wipe clean only.

DESCRIPTION OF PARTS



USING THE VACUUM STORAGE CONTAINER

The vacuum storage container is suitable for storing dry and fresh food. It is not recommended to store liquid in the vacuum storage container.

Place the food to be stored into the storage pot and then secure the lid by repeatedly pressing down on the vacuum pump. As the air is removed and a vacuum seal is created, the vacuum indicator will depress.

Continue to press the vacuum pump until the vacuum indicator is level with the surface of the lid and the clear part of the vacuum indicator is no longer visible.

To remove the lid, press the easy-release button.

Note: Do not attempt to remove the lid whilst the vacuum seal is active.

The dial on the vacuum indicator can be used to monitor how long the food has been vacuum-sealed inside the storage pot. Turn the dial for each subsequent day that the food has been stored.

The vacuum storage container can be placed into the fridge; however, it is not suitable for freezer use.

CLEANING THE VACUUM STORAGE CONTAINER

The vacuum storage container is not dishwasher suitable. Clean the storage pot in warm, soapy water with a mild detergent and a soft cloth; do not use harsh or abrasive cleaners or scourers. Rinse and dry thoroughly.

Do not submerge the lid in water; wipe clean only.

STORAGE

Do not store wet; store in a dry, clean place.

Please retain this information for future reference.

If this product proves unsatisfactory or if you have any further queries, please contact your retailer.



Distributed by:
UP Global Sourcing UK Ltd.,
Victoria Street,
Manchester OL9 0DD. UK.
Made in China.

CD100817/MD000000/V1